



AR80 VL-1S AR100 VL-1S



Varimixer



CONTENTS:

General:	2
Safety:	2
INSTALLATION OF NEW MIXER'	2
Construction of the mixer:	3
THE MIXERS CONTROL PANEL:	3
THE MAXIMUM CAPACITY OF THE MIXER:	4
Recommended maximum speeds:	4
OPERATION OF THE MIXER:	5
Bowl lifting and speed control:	5
Timer function:	
AUTOMATIC LOWERING OF THE BOWL':	6
Pause function:	6
The mixer's start speed after stop:	6
Start-up after stop at high speed:	6
Overload:	6
Software version of the control panel:	6
Correct use of tools:	7
Cleaning:	7
Maintenance and lubrication:	
Grease types:	7
List of errors and Possible solution:	8
Adjustment of special V-belt':	8
Adjustment of bowl fixing:	9
Adjustment of bowl centering:	9
Measuring of bowl height:	9
Adjustment of bowl height:	9
Adjustments of speed (low and high speed cam disks):	. 11
FLECTRICAL DIAGRAMS	12

OBS:

The mixer is to be connected to power via a plug. The plug must be dimensioned for min. 16 A, 230/400V~, IP44

When connecting:

1 phase with 0 + earth, use 3 pole plug

2 phases + earth, use 3 pole plug

3 phases + earth, use 4 pole plug

3 phases with 0 + earth, use 5 pole plug

GENERAL:

In case of complaints, please contact your supplier.

The guarantee does not cover faults resulting from faulty operation, overloading and lacking observance of directions of maintenance.

It should be checked that all loose parts are delivered with the mixer such as bowl, tools, grease gun and rubber feet

If the mixer has an attachment drive only equipment produced by Varimixer A/S must be connected.

SAFETY:

The constant noise level of the workplace of the operator is lower then 70 dB (A).



The mixer is designed for manufacture of products which do not during processing cause reactions or emit substances which may be detrimental to the user.



Putting your fingers in the bowl while the mixer is running may cause injuries.

INSTALLATION OF NEW MIXER:

Installation and securing:

The mixer must be mounted with rubber feet, which neutralize both shaking and rusting. Spacers can be inserted under the mixer's feet, if the floor is not completely even.

The mixer is placed directly on the floor. Foundation bolts in the floor are only necessary under special conditions, e.g. on ships.

Connection to power:


Before the mixer is connected to power, it should be checked that the voltage and frequency printed on the machine label is correct in relation to the place of installation. The machine label is placed at the top right side of the mixer.

Checking of the direction of rotation of the planetary head:




Lift up the bowl arms to normal working position and start the mixer without bowl and tools. Check the direction of rotation of the planetary head: the planetary head must rotate in the direction as stated by the arrow above the planetary head. If the direction of rotation is wrong, 2 of the phase wires of the connecting cable must be inverted.

CONSTRUCTION OF THE MIXER:



THE MIXERS CONTROL PANEL:



Features of the VL-1S control panel:

- Timer
- · Emergency stop
- Pause II
- Start / Stop (i)
- Buttons with changing functions:
 - ↑ Bowl up / Speed up
 - ◆ Bowl down / Speed down
- The speed is reduced to a minimum when the mixer is stopped.
- Automatic lowering of the bowl: When a time is set on the timer and the mixer is running, briefly press ↓. The green LED by ௵ will flash. The bowl will now be lowered automatically when the mixer stops. See also "Automatic lowering of the bowl" on page 6.

THE MAXIMUM CAPACITY OF THE MIXER:

Capacities per mix	Tool	AR80	AR100
Egg white	Whip	12 L	15 L
Whipped cream	Whip	30 L	45 L
Mayonnaise *	Whip	64 L	80 L
Herb butter	Beater	60 kg	75 kg
Mashed potatoes *	Beater/ Whip	50 kg	65 kg
Bread dough (50%AR) **	Hook	50 kg	58 kg
Bread dough (60%AR)	Hook	60 kg	70 kg
Ciabatta dough * (70%AR)	Hook	60 kg	75 kg
Muffins *	Beater	48 kg	60 kg
Layer cake base	Whip	20 kg	25 kg
Meatball mix *	Beater	60 kg	75 kg
Icing	Beater	60 kg	70 kg
Doughnut (50%AR)	Hook	50 kg	60 kg

Local variations in the characteristics of the ingredients can influence water absorption, volume and baking characteristics, etc.

AR = Absorption Ratio (%AR)

(Liquid in % of solids)

Example: A basic recipe contains 1 kg of solids and 0,6 kg of liquid:

This gives AR =
$$\frac{0.6 \text{ kgs } \times 100}{1 \text{ kg}}$$
 = 60%

If for instance it is required to use the maximum capacity of the mixer, the calculated AR = 60% is used for determining the amount of solids and liquid in the dough:


If a 80 L mixer is used, and a dough with AR = 60% is to be kneaded, the maximum capacity is = 60 kg.

Now the weight of solids in this dough is calculated:

Solids =
$$\frac{Max.\ capacity\ x100}{AR + 100} = \frac{60\ kg\ x\ 100}{60 + 100} = 37,50\ kg$$

Weight of liquid = 60 kg - 37,50 kg = 22,50 kg

RECOMMENDED MAXIMUM SPEEDS:



^{*} Scraper recommended

^{**} Low speed operation is recommended

OPERATION OF THE MIXER:

- A Place the tool in the bowl. Open the safety guard.
- B Note: the bowl arms must be in the lowest position. Place the bowl in the bowl arms. Check that the bowl is pushed right back into the arms and that the "centre ear" of the bowl arms are turning in towards the mixer (fig. 2). Place the mixer tool in the bayonet shaft. The tap of the tool must be turned right into the bayonet hole. Close the safety guard.
- C Press to lift the bowl (fig. 3). The bowl will automatically stop in the top position.
- D You can set the mixing time on the timer using the and buttons or you can start the mixer without setting a time. If you do not set a time, the display will function as a clock that counts up. See also "Timer function" on page 6.
- E Press (i) to start the mixer (fig.3).
- F Press ↑ and ↓ until you have reached the desired speed. You can read the speed on the indicator on the side of the mixer (fig. 2). See also "Recommended max. speeds" (fig. 1).
- G During the mixing process the mixer can be paused by pressing II). You can now lower the bowl or open the safety guard. If you start the mixer again using II all the settings will be unchanged. If you start the mixer using the settings will be reset. See also "Pause function" on page 6.
- H When the mixing process is completed the mixer is stopped by pressing , or by the timer going into stop position. In both cases the tool's speed is automatically reduced to a minimum and it will then stop completely.
- When the tool has stopped the bowl can be lowered by pressing .

BOWL LIFTING AND SPEED CONTROL:

The mixer's control panel has two buttons: \uparrow and \downarrow , which both have two functions (fig.3):

- Bowl up or speed up
- Bowl down or speed down

The function of the buttons is determined by whether the mixer is running or not:

- If the mixer is not running, the buttons are used for "bowl up" and "bowl down".
- If the mixer is running, the buttons are used for "speed up" and "speed down".
- When the mixer stops at the end of a process and the tool is still, the buttons are used for "bowl up" and "bowl down".




Fig 2.




Fig. 3 Bowl lifting and speed control.

TIMER FUNCTION:

The mixer has an optional timer function. If no time is set on the timer, the display will instead show the time the mixer has run for.

- The timer can be set to a maximum of 60 minutes.
- and image can be used to set the time before starting the mixer or while the mixer is running. The time can be changed after it has been set.
- When the timer is in use it is important to use II to stop and start the mixer if you do not want the timer to be reset.
- When the time runs out the speed will be reduced to a minimum and the mixer will stop.
- You can select automatic bowl lowering when the timer is in use. Briefly press ↓.

AUTOMATIC LOWERING OF THE BOWL:

- If the timer is in use, the bowl can automatically be lowered when the time runs out and the mixer stops.
- While the mixer is running, briefly press ↓, The green LED by ௵ will flash until the mixer stops.
- When automatic lowering of the bowl is selected it is important that you use II to stop and start the mixer, otherwise the selection will be reset.

Pause function:

The mixer has a pause button (II), which should be used to stop and start the mixer in a process where the timer is used.

- Stop the mixer using II. The timer will continue to count downwards when you start the mixer again by pressing II.
- When you stop the mixer pressing II you can lower the bowl and open the safety guard. When you press
 II again, the timer continues to count downwards.

THE MIXER'S START SPEED AFTER STOP:

Stop using (iii): The mixer's speed is reduced to lowest speed and will start at the lowest speed

Stop by pressing (II): The mixer's speed is reduced to lowest speed and will start at the lowest speed.

Stop using timer runout: The mixer's speed is reduced to lowest speed and will start at the lowest speed.

Stop using emergency stop: The mixer will start at the speed it was stopped at.



Emergency stop must only be used in emergencies.

Stop by opening the safety guard: The mixer will start at the speed it was stopped at.

The safety guard must not be used to stop the machine!

START-UP AFTER STOP AT HIGH SPEED:

If the emergency stop is activated <u>or</u> the safety guard has been opened while lifting or lowering the bowl...

- Release the emergency stop (fig. 3) by turning it anticlockwise or close the safety guard.
- Lifting/lowering of the bowl can be reactivated.

If the emergency stop is activated <u>or</u> the safety guard has been opened while the mixer is running, and you do not want to start up at the same speed...

- First lower the bowl: Start with releasing the emergency stop or close the safety guard. Then take the lid off the mixer and press the small red button on the top side of the control panel while simultaneously pressing .
- Take the tool out of the bayonet.
- Close the safety guard, move the bowl arms up to the top position (empty or with the bowl), start the mixer and run again to the lowest speed by pressing .
- Stop the machine and secure the mixer's lid again. The mixer can now be operated normally.

If the emergency stop is activated <u>or</u> the safety guard has been opened while the mixer is running at low speed, and you want to start up at the same speed...

- Release the emergency stop (fig. 3) by turning it anticlockwise or close the safety guard.
- Press ⁽¹⁾ and the machine will start at the speed it was stopped at. The speed can now be regulated using ↑ and ↓

OVERLOAD:

The mixer must not be overloaded. Sticky and heavy doughs can overload the mixer.



The overload is further exacerbated if the mixer tool's speed is set above the recommended amount or if the wrong mixer tool is used. Larger lumps of fat or chilled ingredients must be reduced before they are put into the bowl.



Longer time overload will interrupt the mixer.

will be written in the mixer's display. After a short while the display will change back to normal mode and you can start the mixer again as described in "Start-up after stop at high speed".

SOFTWARE VERSION OF THE CONTROL PANEL:

- When you turn on the mixer (power is connected to the mixer or the emergency stop is released), the control panel software version can be read on the mixer's display:
- It first displays how many times power has been connected to the mixer.
- It then displays 50:F
- Then it displays the software version.

CORRECT USE OF TOOLS:



The meat mincer must not be used for production of bread crumbs as this will cause unnecessary wear and tear on some mixer parts.



Whips should not be struck against hard objects as e.g. the edge of the bowl. This will make the life of the tool shorter due to increasing deformity.

Recommended applications for tools:

Whip	Beater	Hook
Cream	Cake dough	Bread dough
Egg whites	Butter cream	Dark bread
Mayonnaise	Waffle dough	and the like
and the like	Minced meat	
	and the like	



For production of mashed potatoes the special wing whip or the whip with thicker wires should be used, alternatively use the beater and the whip.

CLEANING:

The mixer should be cleaned daily or after use. The mixer should be cleaned with a soft cloth and clean water. Sulphonated soaps should be used with caution as they destroy the mixer's lubricants.

Never use high pressure cleaning for the mixer.



Parts made of aluminum should not be used to strongly acidic, highly alkaline or highly salty foodstuffs, which may attack aluminum without coating.

Tools of aluminium must not be washed with strong alkaline detergents (pH between 5 and 8).

The soap suppliers can recommend the correct type of soap.



Please note that the plastic safety guard can be damaged if exposed to high temperatures for a considerable period. (Max. temperature 65°C)

Cleaning of attachment drive: after use of the attachment drive this should be wiped inside with a soft cloth.

MAINTENANCE AND LUBRICATION:

The infinitely variable gear must be lubricated regularly, i.e. a lubrication interval of approx. 60 hours of operation.

Lubrication of infinitely variable gear:

OBS. Special grease !!(Use the grease gun delivered together with the mixer). Start the mixer and increase the speed to approx. 50%. Stop the mixer (use the emergency stop) and open the lid on the top of the mixer. On the top of each of the two pulley set shafts is a grease nipple (**fig. 4 point 1**). Press grease through the grease nipples

until the grease gun feels hard to press or until grease comes out between the shaft and the pulleys.



The mixer must not be started until the screws which hold the lid are inserted.

Start the mixer, and set the speed back to low speed.

Stop the mixer and fill the grease gun with new grease so that it is ready for next time.

Lubrication of other movable parts:


The movable parts of the bowl arms, the shaft and the lifting rod must also be lubricated with oil. Remove the rear covering and lubricate the marked points with an oil can. (fig.4 pkt.2)

GREASE TYPES:

Grease for the pulley set shafts: Castrol LMX.

On repair of the planetary head: Grease the toothed wheel and the toothed rim with **Molub Alloy 936SF Heavy** or **Castrol Grippa 355**, the needle bearings in the planetary head must not be lubricated with this type of grease. Do not use any another type of grease than the one stated here.

On repair of the attachment drive: Fill the attachment drive with 0.35 L **STATOIL GreaseWay LiCa 80.**



LIST OF ERRORS: In case of other errors, contact the supplier.

Possible solution:

A rattling sound from the closed part of the mixer.

The mixer starts "striking" when kneading dough which normally causes no problems.

The mixer changes its speed by itself.

The minimum and the maximum speeds are changing.

The bowl is too tight or too loose.

The tool hits the sides of the bowl.

The tool hits the bottom of the bowl.

Adjustment of special v-belt

Adjustment of special v-belt

Adjustment of special v-belt

Adjustment of speed.

Adjustment of bowl fixing

Adjustment of bowl centering

Adjustment of bowl height




(X)

Prior to a possible repair or adjustment, switch off the mixer by disconnecting the power cable.

ADJUSTMENT OF SPECIAL V-BELT:

The distance (X) is only indicative as it depends on the tolerance of the special V-belt.

- 1. Start by tightening the v-belts (*).
- Tighten the special V-belt (A) by moving one or two washers from (V) to (T).
- **3.** Start the mixer and leave it running while the nut **(U)** is tightened. Do not tighten it too much.
- 4. On the front pulley set the stud (**E**) on the varispeed collar (**F**) must be placed inside the lower fork (**G**) and on the rear pulley set outside the fork for belt tightener (**B**), (both must point backwards).
- 5. Tolerances in the transmission might cause that the special V-belt (A) is hitting the pins of the pulley sets when the speed has been adjusted. In such cases the distance (X) must be reduced.
- 6. Then follow the section:
 "Adjustment of speed" page 11



Adjustment of bowl centering:

First find the present bowl centering: mount the beater and the bowl, then raise the bowl arms up to normal working position. With your hand turn the beater, and then measure the distance between beater and bowl edge. By removing the rear covering, the bowl arm guide plate is now accessible (E). Loosen the screws (D) (fig.5) and move the bowl arm guide plate in the required direction. Again turn the beater and measure the distance between beater and bowl. When the bowl has been centred, fasten the bowl arm guide plate in the new position and screw on the rear covering.

ADJUSTMENT OF BOWL FIXING:


The bowl arms must be raised to normal working position. The adjusting diameter **(Y)** shall be measured inside between the bowl arms **(fig.5a)**:

Adjusting diameter (Y): AR80 = 516 mm. Adjusting diameter (Y): AR100 = 554 mm.

In case the bowl fastening is too loose, remove the lock ring **(B)** and draw the bearing **(A)** from the shaft **(C)**. The bearing should be turned 180° and be mounted on the shaft again. It might be necessary to turn both bearings. At last check the bowl centering and if necessary, adjust.

MEASURING OF BOWL HEIGHT:

The distance (X) is measured from the bottom side of the bayonet hole to the surface on the bowl arms on which the bowl rests (fig. 6a). The bowl arms must be lifted to normal working position.



Bowl height (X): AR80 = 233 mm. Bowl height (X): AR100 = 297 mm.


ADJUSTMENT OF BOWL HEIGHT:


The upper and lower position of the bowl is determined by micro switch (1) and (2), (fig. 6).


The two mechanical stops consisting of the bolts (3) and (4) are adjusted so that they will be hit approx. 1 mm after the micro switch, in case the micro switch should fail. The upper position of the bowl arms is adjusted by bending the spring arm on the micro switch (1) forwards or backwards,

It is of utmost importance that the stop screw (3) is readjusted afterwards. In the same way the lower position is adjusted by altering the micro switch (2). It is important that the micro switch is not altered so much that the bowl arms can not hit it.

Thereafter the mechanical stop (4) is adjusted.







ADJUSTMENTS OF SPEED (LOW AND HIGH SPEED CAM DISKS):

Prior to any adjustment the, the bowl must be in its top position and the safety guard must be closed.

Switch off the power to the mixer, this must be done via the emergency stop. Remove the lid of the mixer.

Dismantle shaft for speed regulation: The arm **(B)** is released from the servo motor shaft by removing the cotter pin **(C)** and the pin **(D)**. The arm **(B)** must not be loosened from the shaft **(E)**.

Loosen the screw (F) and take out the speed indicator (G).

Loosen the screw in the speed indicator clamp (H) and remove the disk with arrow (I)

The manual speed selector handle (J) is placed in the shaft (E) so that it points upwards and forwards.

Release the emergency stop and start the mixer.

Turn the handle for manual adjusting of speed to minimum speed until the distance from the v-belt to the edge of the planetary head pulley is approximately 1 mm. see **fig. 7a**.

Stop the mixer by pressing emergency stop.

Loosen the two screws on the two cam disks (K) and (L).

Turn the cam disk for minimum speed (K) until it is activating the micro switch. Tighten the screw.

Release the emergency stop and start the mixer.

Turn the handle for manual adjusting of speed to maximum speed until the distance from the v-belt to the edge of the motor pulley is approximately 3 mm. see **fig. 7b**.

Stop the mixer by pressing emergency stop.

Turn the cam disk for maximum speed (L) until it is activating the micro switch. Tighten the screw.

Remove the manual speed selector handle


Remount the servo motor shaft on the arm **(B)**. It is urgent to make sure that the servo motor is not clamped against the machine column, the shaft **(E)** or other parts of the mixer, and that the "bad position" **(Fig. 8)** for the motor is avoided.


If the servomotor is not positioned correctly (according to the description above), the two screws **(M)** and **(N)** that fixates the arm on the shaft are loosened and the arm adjusted. Now the handle for manual speed adjustment has to be mounted again and the cam discs must be adjusted once again.


When the min. and max. speed has been adjusted correctly, the speed indicator clamp, the disk with arrow and the speed indicator are remounted.

Cam disks for minimum and maximum speed have now been adjusted.

ELECTRICAL DIAGRAMS:







Indhold af Overensstemmelseserklæring, (Maskindirektivet, 2006/42/EC, Bilag II, del A)	DK
Contents of the Declaration of conformity for machinery, (Machinery Directive 2006/42/EC, Annex II., sub. A)	EN
Inhalt der Konformitätserklärung für Maschinen, (Richtlinie 2006/42/EG, Anhang II, sub A)	DE
Contenu de la Déclaration de conformité d'une machine, (Directive Machine 2006/42/CE, Annexe II.A)	FR
Inhoud van de verklaring van overeenstemming voor machines, (Richtlijn 2006/42/EC, Bijlage II, onder A)	NL
Contenido de la declaración de conformidad sobre máquinas, (Directiva 2006/42/EC, Anexo II, sub A)	ES

Fabrikant; Manufacturer; Hersteller; Fabricant; Fabrikant; Fabricante:

Adresse; Address; Adresse; Adresse; Adres; Dirección:

Varimixer A/S

Kirkebjerg Søpark 6, DK-2605 Brøndby, Denmark

Navn og adresse på den person, som er bemyndiget til at udarbejde teknisk dossier Name and address of the person authorised to compile the technical file Name und Anschrift der Person, die bevollmächtigt ist, die technischen Unterlagen zusammenzustellen Nom et adresse de la personne autorisée à constituer le dossier technique naam en adres van degene die gemachtigd is het technisch dossier samen te stellen nombre y dirección de la persona facultada para elaborar el expediente técnico

Navn; Name; Name; Nom; Naam; Nombre:

Adresse; Address; Adresse; Adresse; Adres; Dirección:

Sted, dato; Place, date; Ort, Datum; Lieu, date; Plaats, datum; Place, Fecha:

Kim Jensen Kirkebjerg Søpark 6, DK-2605 Brøndby, Denmark

Brøndby, 14-03-2018

Erklærer hermed at denne røremaskine Herewith we declare that this planetary mixer Erklärt hiermit, dass diese Rührmaschine Déclare que le batteur-mélangeur ci-dessous Verklaart hiermede dat Menger Declaramos que el producto batidora

- er i overensstemmelse med relevante bestemmelser i Maskindirektivet (Direktiv 2006/42/EC) is in conformity with the relevant provisions of the Machinery Directive (2006/42/EC) konform ist mit den Bestimmungen der EG-Maschinenrichtlinie (Direktiv 2006/42/EG) Satisfait à l'ensemble des dispositions pertinentes de la Directive Machines (2006/42/CE) voldoet aan de bepalingen van de Machinerichtlijn (Richtlijn 2006/42/EC) corresponde a las exigencias básicas de la Directiva sobre Máquinas (Directiva 2006/42/EC)
- er i overensstemmelse med følgende andre CE-direktiver is in conformity with the provisions of the following other EC-Directives konform ist mit den Bestimmungen folgender weiterer EG-Richtlinien Est conforme aux dispositions des Directives Européennes suivantes voldoet aan de bepalingen van de volgende andere EG-richtlijnen está en conformidad con las exigencias de las siguientes directivas de la CE

2014/30/EU; 1935/2004; 10/2011; 2023/2006; RoHS 2011/65/EU, 822/2013 (DK only)

Endvidere erklæres det And furthermore, we declare that Und dass Et déclare par ailleurs que En dat Además declaramos que

> at de følgende (dele af) harmoniserede standarder, er blevet anvendt the following (parts/clauses of) European harmonised standards have been used folgende harmonisierte Normen (oder Teile/Klauseln hieraus) zur Anwendung gelangten Les (parties/articles des) normes européennes harmonisées suivantes ont été utilisées de volgende (onderdelen/bepalingen van) geharmoniseerde normen/nationale normen zijn toegepast las siguientes normas armonizadas y normas nacionales (o partes de ellas) fueron aplicadas

EN454:2014 ; EN60204-1:2006; EN12100-2011

EN61000-6-1:2007; EN61000-6-3:2007

Innehåll i örsäkran om maskinens överensstämmelse, (Maskindirektivet 2006/42/EG, bilaga 2, A) Contenuto della dichiarazione di conformità per macchine, (Direttiva 2006/42/CE, Allegato II, parte A) Sisukord masina vastavusdeklaratsioon, (Masinadirektiiv 2006/42/EÜ, lisa II, punkt A) Treść Deklaracja zgodności dla maszyn (Dyrektywa maszynowa 2006/42/WE, Załącznik II, pkt A)				
Sisältö vaatimustenmukaisuusvakuutus koneesta (Konedirektiivi 2006/4				
Tillverkare; Fabbricante; Tootja; Producent; Valmistaja:	Varimixer A/S			
Adress; Indirizzo; Aadress; Adres; Osoite:	Kirkebjerg Søpark 6, DK-2605 Brøndby, Denmark			
Namn och adress till den person som är behörig att ställa samman den tekniska o Nome e indirizzo della persona autorizzata a costituire il fascicolo tecnico Tehnilise kausta volitatud koostaja nimi ja aadress Imię i nazwisko oraz adres osoby upoważnionej do przygotowania dokumentacji Henkilön nimi ja osoite, joka on valtuutettu kokoamaan teknisen tiedoston				
Namn; Nome e cognome; Nimi; Imię i nazwisko; Nimi:	Kim Jensen			
Adress; Indirizzo; Aadress; Adres; Osoite:	Kirkebjerg Søpark 6, DK-2605 Brøndby, Denmark			
Ort och datum; Luogo e data; Koht, kuupäev; Miejscowość, data; Paikka, aika:	Brøndby, 14-03-2018			

Försäkrar härmed att denna blandningsmaskin Con la presente si dichiara che questo mixer planetaria Deklareerime käesolevaga, et Planetaarmikseri Niniejszym oświadczamy, że mikser planetarny vakuuttaa, että tämä mikseri tyyppi

- överensstämmer med tillämpliga bestämmelser i maskindirektivet (2006/42/EG) is è conforme alle disposizioni della Direttiva Macchine (Direttiva 2006/42/CE) vastab kehtivatele masinadirektiivi (2006/42/EÜ) nõuetele spełnia wymagania odpowiednich przepisów dyrektywy maszynowej (2006/42/WE) on konedirektiivin (2006/42/EY) asiaankuuluvien säännösten mukainen
- överensstämmer med bestämmelser i följande andra EG-direktiv è conforme alle disposizioni delle seguenti altre direttive CE vastab järgmiste EÜ direktiivide nõuetele spełnia wymagania przepisów innych dyrektyw WE on seuraavien muiden EY-direktiivien säännösten mukainen

2014/30/EU; 1935/2004; 10/2011; 2023/2006; RoHS 2011/65/EU; 822/2013 (DK only)

Vi försäkrar dessutom att e che Lisaks ülaltoodule deklareerime, et Ponadto oświadczamy, że ja lisäksi vakuuttaa, että

> följande (delar/paragrafer av) europeiska harmoniserade standarder har använts sono state applicate le seguenti (parti/clausole di) norme armonizzate kasutatud on järgmisi Euroopa harmoniseeritud standardeid (või nende osi/nõudeid) zastosowano następujące części/klauzule zharmonizowanych norm europejskich seuraavia eurooppalaisia yhdenmukaistettuja standardeja (tai niiden osia/kohtia) on sovellettu

EN454:2014 ; EN60204-1:2006; EN12100-2011
EN61000-6-1:2007; EN61000-6-3:2007
DS/EN 1672-2 + A1:2009



Kirkebjerg Søpark 6 DK-2605 Brøndby Denmark Phone: 43 44 22 88 info@varimixer.com www.varimixer.com